CRAFTSMAN®

PARTS LIST FOR 14 PC INCH COMBINATION WRENCH SET W/POUCH #35833

Congratulations on your purchase of a quality **CRAFTSMAN** Tool Set.
Should you have any questions about the tools you've just purchased, save some time and call our toll-free Customer Service Number which is **1-800-832-7494.**
We are open Monday through Friday from 8:00 a.m. to 4:30 p.m. Eastern Standard-Time.

CAT. NO.		DESCRIPTION	DRIVE SIZE
44699	1/4"	COMBINATION WRENCH INCH	
44691	5/16"	COMBINATION WRENCH INCH	
44692	11/32"	COMBINATION WRENCH INCH	
44693	3/8"	COMBINATION WRENCH INCH	
44694	7/16"	COMBINATION WRENCH INCH	
44695	1/2"	COMBINATION WRENCH INCH	
44696	9/16"	COMBINATION WRENCH INCH	
44697	5/8"	COMBINATION WRENCH INCH	
44698	11/16"	COMBINATION WRENCH INCH	
44701	3/4"	COMBINATION WRENCH INCH	
44702	13/16"	COMBINATION WRENCH INCH	
44703	7/8"	COMBINATION WRENCH INCH	
44704	15/16"	COMBINATION WRENCH INCH	
44705	1"	COMBINATION WRENCH INCH	

CRAFTSMAN HAND TOOL FULL WARRANTY

If any Craftsman Hand Tool ever fails to give complete satisfaction, return it to any Sears store or other Craftsman Outlet in the United States for free repair or replacement. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

SEARS, ROEBUCK AND COMPANY, HOFFMAN ESTATES, IL 60179